


Troubleshooting Guide for the ST160 Foam Injector & ST75/175 Foam Lance



PLEASE NOTE

The Suttner range of ST160 injectors will **not** work if:

- A K Series injector is fitted, as it won't work with the ST75. An ST72 or the ST75.1 foam lances are required instead
- There is already a chemical injector fitted to the pressure washer/system.
- If the water temperature when foaming exceeds 50°C. (upto 90°C on rinse)

please call our technical

team

- The hose is wound onto a hose reel. (The hose needs to be fully unwound for the injector to work correctly.)
- The hose has been joined to another hose.
- If there is some sort of vario-press or other pressure adjuster in the system.

TECHNICAL TEAM: Tel: 01768 865985 Email: info@gspen.co.uk

get in?

If you are still having

problems, please call our technical team



please call our technical

team